

Display Share 2

Wirelessly broadcast, mirror, and control from any device.



Download the app



displayshare.optoma.com

Skip the app



Send/Receive w/Touch



Send/Receive w/Touch



Send/Receive


Connecting your device

Option 1: Display Share 2 app

Option 2: Airplay


1

Choose your device




2

Enter pin code



3

Begin sharing




Connecting your device

Option 1: Display Share 2 app

Option 2: Miracast ( + K)

1

Name device and customize settings




2

Choose device and connect




3

Choose source and click “Share Screen”




4

Annotate, pause, or stop sharing




Home Screen Layout

Connection Information & Settings



Display Group Settings

Duplicate content to other Optoma displays




HD Mode (Default)
UHD Mode (4K)
Only valid during screen sharing
Disable

Auto-accept
Notify me
Disable

Moderator Control Center

Share, view, control, touch, & connected devices



All allowed
Needs authorization
Disable

All allowed
View only
Needs authorization
Disable

Always show
Only on home screen
Disable
Auto

Dashboard

Display Group
Settings

Settings

General connection settings

