


One Click SOP

This firmware upgrade tool is designed for Optoma Projector

OS support: Windows 11/Windows 10/Windows 7

Note: Please do not power off the projector while updating the system.

1. Long press [Power + Enter] on projector's keypad and then plug in the power cord until all the LEDs light up to enter download mode.




2. Connect Projector and PC via USB cable.




3. Open one click FW "xxx.exe"

Name	Status
x86	✓
check_USB	✓
Optoma_EX1_DAZKHSZST_C12_OneClick...	✓
upgrade	✓

4. Click "Download" Button.



5. Wait for upgrade to complete



```
C:\Windows\system32\cmd.exe
Building the list of sectors to program (200 of 212)
Skipping sector (200)
Building the list of sectors to program (201 of 212)
Skipping sector (201)
Building the list of sectors to program (202 of 212)
Skipping sector (202)
Building the list of sectors to program (203 of 212)
Skipping sector (203)
Building the list of sectors to program (204 of 212)
Skipping sector (204)
Building the list of sectors to program (205 of 212)
Skipping sector (205)
Building the list of sectors to program (206 of 212)
Skipping sector (206)
Building the list of sectors to program (207 of 212)
Skipping sector (207)
Building the list of sectors to program (208 of 212)
Skipping sector (208)
Building the list of sectors to program (209 of 212)
Skipping sector (209)
Building the list of sectors to program (210 of 212)
Skipping sector (210)
Building the list of sectors to program (211 of 212)
Skipping sector (211)
Building the list of sectors to program (212 of 212)
Skipping sector (212)
No sectors to program
C:\Users\manning_ding\Desktop\Optima_EU2_ZK420UST_B05_OneClick\>pause
Press any key to continue . . .
```

6. Unplug the power cable on the projector, wait 10 seconds, then insert power cable.

7. Power-on Projector.

8. Upgrade process is now complete.